

plusmodel

007 Zeď s kovovými vraty Wall with metal gate

Návod ke stavbě

Při stavbě postupujte podle instruktážních obrázků.

Upozornění: Během opracování může vznikat prach, který může dráždit dýchací cesty. Používejte ochranu očí při odstřihování kovových dílů.

Instructions

Follow the instruction drawings the assembly

Notice: Machining can produce dust which can be irritating to the respiratory tract. Metal parts should be cut off using protection eyesight.

MODELCHOICE.NET

ORDER & BUY DIRECTLY FROM MANUFACTURERS

Plus Model s.r.o
Jižní 56, 370 10 České Budějovice
Czech Republic
<http://www.plusmodel.cz>
e-mail: plusmodel@plusmodel.cz

Instructions:

1. At first, clean all parts from flashes and grind them on their bearing surfaces to fit well.
2. Cut out metal parts from sheet and cement on the place according the instruction drawing. Gypsum is tender and holder of the gate hinges can be pressed in. See to it that the hinges are in the same height. Cement locks and handles.
3. Get all wall parts together. Use some suitable glue (white glue).
4. The wall can be glued together in several different variants - as the straight or corner wall.
5. Fill appropriate gaps with the putty prepared from the thinner gypsum paste, you can use the brush. Scrape superfluous gypsum off the when the putty is partially dry and smooth the surface by a wet brush or finger.
6. Color finishing depend on your own consideration only, but some pale shades are recommended. To decrease color consumption, coat all gypsum parts by some varnish before the painting.

Návod sestavení:

1. Všechny díly nejprve očistěte od ořepů a pečlivě zabrušte všechny dosešedací plochy.
2. Vyřizněte kovové díly z plechu a nalepte dle obrázků. Sádra je měkká a držáky pantů do ní můžete zamačknout. Pozor, aby jste měli oba panty vrat ve stejné výšce. Dolepte zámkový a klikový.
3. Slepíte jednotlivé díly zdi pomocí disperzního lepidla (Herkules, Gammafix ...)
4. Zeď můžete slepit v několika variantách - rovnou, rohová, vrata a vrátka u sebe nebo zvlášť...
5. V případě tmelení použijte jako tmelu řídkou sádku.
6. Před natíráním je vhodné všechny sádrové díly natřít lakem. Snížíte tím savost podkladu a spotřebu barvy. Dejte sádrových keramických dílů a aršík s kovovými díly.

