

# German bunker

- 1) Dle obrázku slepte hlavní díly diorama.
- 2) Do díry ve stropě vlepěte tankovou věž do které jste předtím vlepili hlaveň kanonu.
- 3) Panceřové dveře vlepěte do vchodu bunkru.
- 4) Dle titulního obrázku nalepte krycí zeď.
- 5) Do mezery mezi krycí zdí a bunkrem vsadte dřevěný rošt, který jste udělali z příložených listů a prkýnek.
- 6) Jednotlivé díly diorama je nejlepší lepit disperzním lepidlem Herkules atp.
- 7) Dle titulního obrázku a z příloženého drátu udělejte na boku bunkru stupačky.
- 8) V případě tmelení použijte jako tmelu řídkší sádku.
- 9) Před natíráním je vhodné základ diorama (mimo věž) přetřít lakem. Snížíte tím savost podkladu a spotřebu barvy.

- 1) Cement the main parts together according to the picture.
- 2) Cement the tank tower with the cannon barrel into the hole in the roof.
- 3) Cement armored door into the entrance.
- 4) Cement protecting wall according to the picture on the package.
- 5) Put the a wooden grill (made from the attached wooden beams) into the recess between the protecting wall and the shelter.
- 6) A dispersion (white) glue is recommended.
- 7) Make steps according to the picture on the package using the attached wire.
- 8) Use thin plaster for necessary filling.
- 9) It is suitable to overspray the shelter (excluding the tank tower) with a clear lacquer before painting - it helps you to spare color otherwise absorbed by the porous material.

